

NOTE: All products shown are NEMA 4X & rated -40° to 55° C. (-40° to 131° F.) by the manufacturer. Actual appearance may differ from depictions. For more information, see Rockwell Automation, Inc. "Bulletin 800T/H 30 mm Push Buttons".

Model No.	Description	
Spring Return (to Off) Position Switch		
12-9577-03	Red - Open/Green - Close	
12-9577-04	Red - Close/Green - Open	
Maintain (Open/Off/Close) Position Switch		
12-9577-25	Red - Open/Green - Close	
12-9577-26	Red - Close/Green - Open	

Provides visual indication that the actuator is at either end of travel (or any other 2 points in travel selected by the customer). Also allows movement of the actuator in either direction through use of a HAND/AUTO (Manual/Automatic) switch and an OPEN/CLOSE spring return to OFF switch. The OPEN/CLOSE return to OFF switch is also available as non-spring return (maintain position).

Model No.	Description		
Spring Return (to Off) Position Switch			
12-9577-02	Red - Open/Green - Close		
12-9577-06	Red - Close/Green - Open		
Maintain (Open/Off/Close) Position Switch			
12-9577-01	Red - Open/Green - Close		
12-9577-05	Red - Close/Green - Open		


Provides visual indication that the actuator is at either end of travel (or any other 2 points in travel selected by the customer). Also allows movement of the actuator in either direction through use of a spring return switch. Switch is also available as non-spring return (maintain position).

PILOT LIGHT INDICATION

> AUTO/MANUAL STATION W/ DIGITAL DISPLAY KIT

Model No.	Description
12-9577-07	Red - Open/Green - Close
12-9577-08	Red - Close/Green - Open

Provides visual indication that the actuator is at either end of travel (or any other 2 points in travel selected by the customer).



Allows movement of the actuator in either direction through use of a HAND/AUTO (Manual/Automatic) switch and an OPEN/ CLOSE spring return to OFF switch. Switch is also available as non-spring return (maintain position). Kit includes a looppowered LCD 0–100% position indicator (digital display).










AUTO / MANUAL STATION


W/ INDICATION

AUTO / MANUAL STATION WITH INDICATION




AUTO / MANUAL STATION WITH INDICATION

TYPICAL WIRING CONNECTIONS




*NOTE: All dimensions subject to change without notice. Push to test LED "OPEN" & "CLOSE" nameplates may be switched as necessary to match application requirements.


MANUAL STATION WITH INDICATION



FRONT


TYPICAL WIRING CONNECTIONS






*NOTE: All dimensions subject to change without notice. Push to test LED "OPEN" & "CLOSE" nameplates may be switched as necessary to 4 match application requirements.

PILOT LIGHT INDICATION




TYPICAL WIRING CONNECTIONS

(may vary depending upon actuator model and options) <Terminal Wire capacity = #18–#14 AWG (0.75–2.5 mm²); max. = (2) #14 AWG or (1) #12 AWG>




*NOTE: All dimensions subject to change without notice. Push to test LED "OPEN" & "CLOSE" nameplates may be switched as necessary to 5 match application requirements.

AUTO / MANUAL STATION WITH DIGITAL DISPLAY (KIT)



*NOTE: All dimensions subject to change without notice.






*NOTE: Dimensions provided by the manufacturer are shown for convenience and are subject to change without notice.


AUTO / MANUAL STATION WITH DIGITAL DISPLAY (KIT)


TYPICAL WIRING CONNECTIONS


(may vary depending upon actuator model and options) <Terminal Wire capacity = #18–#14 AWG (0.75–2.5 mm²); max. = (2) #14 AWG or (1) #12 AWG>



TERMINAL NUMBER IDENTIFICATION







All of the individual terminal boards are the same -the terminals are oriented and numbered the same. The number of terminal boards will vary depending upon the indication station type.

HAROLD BECK & SONS, INC. Mac 11 TERRY DRIVE • NEWTOWN, PENNSYLVANIA 18940 • USA PHONE: 215-968-4600 • FAX: 215-860-6383 • E-MAIL: sales@haroldbeck.com www.haroldbeck.com

